



Samsung Galaxy Note5 Middle Housing Replacement

Written By: Sophia



INTRODUCTION

[video: <https://www.youtube.com/watch?v=Q5V-JJPt6Ng>]



TOOLS:

- [Heat Gun](#) (1)
- [iFixit Opening Picks set of 6](#) (1)
- [Suction Handle](#) (1)
- [Phillips #000 Screwdriver](#) (1)



PARTS:

- [Galaxy Note5 SIM Card Tray](#) (1)
- [Galaxy Note 5 Speaker](#) (1)
- [Galaxy Note5 Rear Camera Bezel Lens Cover](#) (1)

Step 1 — Middle Housing




- Remove SIM card tray.

Step 2



- Remove S Pen.

Step 3



- Remove back cover.

Step 4



- Remove screws.

Step 5



- Push to separate the middle housing from front assembly. There is a little adhesive around every corner. The middle housing comes with power button flex, volume button flex, loudspeaker and wireless charging film.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-18 03:02:31 PM.